

# YAMAHA TDM



USE CABLE C7, REMOVE BACK PLASTIC COVER FROM DASH, AFTER LOCATING POINTS ON THE MAIN BOARD, SOLDER CABLE LEADS CONCORDANCE WITH ITS NUMBER-COLOUR:

