

ALFA ROMEO 166 FROM 2002



USE CABLE C4, REMOVE BACK PLASTIC COVER OF DASH, THEN LOCATE EPROM, AND CLIP IT CHECKING **PIN 1** AS SHOWN OF BELOW PHOTO:

