

ALFA ROMEO 166 TO 2002



USE CABLE C11 - HC11, REMOVE BACK COVER FROM DASH, PULL MAIN BOARD OUT AND THEN SOLDER CABLE LEADS ACCORDING TO COLOURS AS SHOWN ON THE PHOTOS BELOW:



