

# ALFA ROMEO GT



USE CABLE C4 - CLIP SMD, ONCE OPEN DASH BOTH OUTSIDE BLACK COVERS, THEN APPEARS CLOCK, TAKE NAILS OFF AND CAREFULLY MOVE SCREEN LIKE YOU CAN SEE INTO PHOTOS. THEN TAKE OFF ALL CREWS ON THE WAY AND PLASTICS, DOWN IT IS EPROM LOCATED. YOU MUST CLIP IT AS YOU CAN SEE IMAGE FROM DOWN TAKING CARE FROM PIN NUMBER 1.

