

# AUDI A3 UK-NSI



USE CABLE C4, OPEN BACK PART OF DASH, THEN LOCATE EPROM, SOMETIMES MUST BE CLEANED, AND CLIP IT CHECKING **PIN 1** AS SHOWN OF BELOW PHOTO:

