AUDI A4 UK-NSI 1997



USE CABLE **C4**, OPEN BACK COVER FROM DASH, THEN LOCATE EPROM, SOMETIMES MUST BE CLEANED, AND CLIP IT CHECKING PIN 1 AS SHOWN TO US PHOTO BELOW:

