## AUDI A4 UK-NSI FROM 1997



USE CABLE C4, OPEN ALL DASH, CAREFULLY, THEN LOCATE EPROM, SOMETIMES MUST BE CLEANED, AND CLIP IT CHECKING PIN 1 AS SHOWN OF BELOW PHOTO:

