AUDI A4 UK-NSI To 1997



USE CABLE C4, OPEN ALL DASH, TO REMOVE MAIN BOARD YOU SHOULD TAKE OFF ENGINES SCREWS, THEN LOCATE EPROM, SOMETIMES MUST BE CLEANED, AND CLIP IT CHECKING PIN 1 AS SHOWN OF BELOW PHOTO:

