

BMW EWS 4.X

USE CABLE **C45 + A6 ADAPTER**.
REMOVE MODULE FROM CAR.



CAREFULLY, OPEN, LOCATE POINTS IN THE BOARD AND SOLDER CABLE LEADS AS SHOWS TO US BELOW PHOTO:

