

BUICK RENDEZVOUS



USE CABLE C4, OPEN ALL DASH CAREFULLY, THEN LOCATE EEPROM 95020 AND CLIP IT CHECKING **PIN 1** AS WE CAN SEE ON THIS PHOTO BELOW:

