

CHEVROLET AVEO FROM 2007



USE CABLE C4, REMOVE ALL PLASTIC COVERS FROM OUTSIDE, NOW CAREFULLY PULL OUT NAILS, AND THEN BACK, WHEN WE HAVE WHITE PLASTIC, U CAN CHOOSE TO DESOLDER SCREEN OR MAKE A LITTLE HOLE ON THIS COVER. LOCATE EPROM MEMORY, AND CLIP IT CHECKING **PIN 1** AS SHOWN OF PHOTO BELOW:

