

CHEVROLET CORVETTE 2000



Use C7 CABLE, OPEN ALL DASH AND LOCATE POINTS IN THE MAIN BOARD LIKE IN PHOTO BELOW. NOW ONLY SOLDER CABLE LEADS AS IT SHOWS TO US.

