

CHEVROLET CORVETTE 2006



USE CABLE C4, OPEN ALL DASH CAREFULLY, LOOK FOR EPROM 93C76 AND WHEN WE HAVE IT IN FRONT OF US, CLIP IT CHECKING PIN 1 AS SHOWN OF PHOTO BELOW:

