

CHEVROLET EPICA



USE CABLE C4, REMOVE BACK PLASTIC COVER, LOCATE EPROM MEMORY 93C46, AND CLIP IT CHECKING **PIN 1** AS SHOWN OF PHOTO BELOW:

