

CHEVROLET MATIZ



USE CABLE C11, REMOVE BACK PLASTIC COVER FROM DASH, LOCATE POINTS ON THE BOARD, AND SOLDER CABLE LEADS ACCORDING TO COLOURS AS SHOWN OF BELOW PHOTO:

