

# CHRYSLER SEBRING 2007



USE CABLE C12, OPEN BACK COVER FROM DASH, THEN CONNECT OR SOLDER CABLE LEADS ACCORDING TO COLOURS AS SHOWN OF BELOW PHOTO:

