

CITROEN C3 BSI FROM 2005



USE CABLE C7, REMOVE BACK PLASTIC COVER FROM BSI, THEN CONNECT OR SOLDER CABLE LEADS ACCORDING TO PIN AS SHOWN OF BELOW PHOTO:

