

CITROEN C3 BSI TO 2005



USE CABLE C4, REMOVE BACK PLASTIC COVER FROM BSI, THEN LOCATE EEPROM AND CLIP IT CHECKING PIN 1 AS SHOWN OF PHOTO BELOW:

