


# CITROEN C4 BSI



USE CABLE C4, REMOVE BACK PLASTIC COVER FROM BSI, THEN LOCATE EEPROM MEMORY AND CLIP IT CHECKING PIN 1 AS SHOWN OF PHOTO BELOW:

