

CITROEN C8 BSI TO 2005



USE CABLE C12 O HCS12,
REMOVE BACK PLASTIC COVER FROM BSI, THEN CONNECT OR SOLDER CABLE
LEADS ACCORDING TO COLOURS AS SHOWN OF BELOW PHOTO:

