

CITROEN XSARA BSI FROM 2002



USE CABLE C7, TAKE OFF BACK SIDE FROM BSI, THEN CONNECT OR SOLDER CABLE LEADS ACCORDING TO PIN AS SHOWN OF BELOW PHOTO:

