

# DAIHATSU COPEN



Use C7 CABLE, OPEN BACK SIDE FROM DASH, AND LOCATE POINTS IN THE BOARD LIKE IN PHOTO BELOW AND SOLDER CABLE LEADS AS IT SHOWS TO US:

