

# FERRARI 550 - 575 MARANELLO



USE CABLE C4, OPEN BACK PART OF DASH, CAREFULLY, THEN LOCATE EPROM 24C02 MEMORY, AND CLIP IT CHECKING **PIN 1** AS SHOWN OF PHOTO BELOW:

