

FERRARI F430 STRADALE



USE CABLE C4, OPEN BACK PART OF DASH, CAREFULLY, THEN LOCATE MEMORY, A 24C16 EPROM, AND CLIP IT CHECKING PIN 1 AS SHOWN OF PHOTO BELOW:

