

# FIAT ULYSSE BSI FROM 2006



USE CABLE C7, REMOVE BACK PLASTIC COVER FROM BSI, THEN CONNECT OR SOLDER CABLE LEADS ACCORDING TO PIN AS SHOWN OF BELOW PHOTO:

