

FORD MAVERICK TO 2004



USE CABLE C11, REMOVE BACK COVER FROM DASH, THEN CONNECT OR SOLDER CABLE LEADS ACCORDING TO COLOURS AS SHOWN ON PHOTO, REMEMBER TO LIF UP ONE PIN FROM MICRO:

