

FORD MONDEO TO 2006



USE CABLE C12 - HCS12, CONNECT OR SOLDER ON THE BACK OF DASH CABLE LEADS ACCORDING TO COLOURS AS SHOWN ON THE PHOTO BELOW:

