

# HONDA CBR 600F 2001-2005



USE C7 CABLE, OPEN BACK COVER OF DASH, LOCATE POINTS IN THE MAIN BOARD LIKE IN PHOTO BELOW AND SOLDER CABLE LEADS AS IT SHOWS TO US:

