

# HONDA CIVIC TO 2006



USE C7 CABLE, OPEN DASH, LOCATE POINTS IN THE MAIN BOARD LIKE IN PHOTO BELOW AND SOLDER CABLE LEADS AS IT SHOWS TO US:

