

HONDA CRV TO 2004



USE CABLE C7, OPEN BACK COVER FROM DASH, AND THEN LOCATE POINTS IN THE MAIN BOARD LIKE IN PHOTO BELOW AND SOLDER CABLE LEADS AS IT SHOWS TO US:

