


HONDA VFR800 V-TEC FROM 2005



USE C7 CABLE, OPEN BACK COVER OF DASH, LOCATE POINTS IN THE MAIN BOARD LIKE IN PHOTO BELOW AND SOLDER CABLE LEADS AS IT SHOWS TO US:

