

HYUNDAI ACCENT NEC TO 2006



Use **CABLE C13** ALWAYS CONNECTED TO **A1** ADAPTER. OPEN COMPLETELY DASH, BE CAREFULLY WITH SCREEN, THEN CONNECT OR SOLDER CABLE LEADS ACCORDING TO NUMBER AS SHOWN IN NEXT PHOTO:

