

HYUNDAI MATRIX



USE C7 CABLE, REMOVE BACK SIDE OF DASH, THEN LOCATE POINTS ON THE MAIN BOARD LIKE IN PHOTO BELOW AND SOLDER CABLE LEADS AS IT SHOWS TO US:

