

# HYUNDAI TUCSON FROM 2006



USE CABLE C5, OPEN BACK PLASTIC COVER FROM DASH, BE CAREFULLY, AND THEN LOCATE EPROM 93C56, AND CLIP IT CHECKING PIN 1 AS SHOWN OF BELOW PHOTO:

