

JCB



USE CABLE C4, OPEN DASH REMOVING GLASS AND SCREWS, THEN LOCATE EPROM, AND CLIP IT CHECKING PIN 1 AS SHOWN IN THE PHOTO BELOW:

