

KAWASAKI ZX6-R NINJA To 2000



Use CABLE C7, OPEN BACK PLASTIC COVER FROM DASH, THEN LOCATE EEPROM POINTS, AND SOLDER CABLE LEADS CHECKING NUMBERS AND COLOURS AS SHOWN INTO BELOW PHOTO:

