

KAWASAKI ZX9 TO 2000



USE CABLE C7, OPEN BACK PLASTIC COVER FROM DASH, THEN LOCATE EEPROM POINTS, AND SOLDER CABLE LEADS CHECKING NUMBERS AND COLOURS AS SHOWN INTO BELOW PHOTO:

