

LANCIA KAPPA FROM 1999



USE CABLE C11 - HC11, REMOVE BACK COVER FROM DASH, THEN CONNECT OR SOLDER CABLE LEADS ACCORDING TO COLOURS AS SHOWN ON THE PHOTO:

