

# LAND ROVER DEFENDER TO 2006



USE CABLE C4, OPEN DASH REMOVING GLASS AND 3 TORX, THEN LOCATE EPROM, AND CLIP IT CHECKING **PIN 1** AS SHOWN IN THE PHOTO BELOW:

