

LAND ROVER FREELANDER TO 2001



USE C7 CABLE, REMOVE ONLY SPEDOMETER, IT IS THE SCREEN ONE, THEN WE CAN SEE THE 93C46 EPROM, AND WITH THE PHOTO BELOW WE CAN SOLDER CABLE LEADS ACCORDING TO COLOUR:

