

# MAZDA 626 FROM 2001



USE CABLE C4, OPEN BACK SIDE OF DASH, CAREFULLY, THEN LOCATE EPROM MEMORY, AND CLIP IT CHECKING **PIN 1** AS SHOWN OF BELOW PHOTO:

