

# MAZDA 626 TO 2000



USE CABLE C7, OPEN BACK COVER FROM DASH, LOCATE POINTS ON THE MAIN BOARD LIKE IN PHOTO BELOW AND SOLDER CABLE LEADS AS IT SHOWS TO US:

