

MERCEDES BENZ A-W169 ZGS

USE CABLE C12. REMOVE FROM CAR, IT'S BACK FROM DASH, AND OPEN IT:



NEXT SOLDER CABLE LEADS ACCORDING TO COLOURS AS SHOWN ON PHOTO BELOW:

