MercedesBenz B-W245 ZGS

Use cable C12. Remove from car, it´s back from dash, and open it:

LOCATION

Next solder cable leads according to colours as shown on photo below: