

# MERCEDES BENZ SPRINTER EZS FROM 2006

USE CABLE **C45 + A6 ADAPTER**. REMOVE MODULE FROM CAR CAREFULLY:



NOW REMOVE BACK PLASTICS COVERS FROM EZS, AND LOCATE POINTS ON THE BOARD LIKE IN PHOTO BELOW AND SOLDER CABLE LEADS AS IT SHOWS TO US:

