## MERCEDESBENZ SPRINTER KIENZLE TO 2000



USE IN THIS KIND OF DASH, TILL 2000 AND REMOVE PROTECTION FROM IT:



USE SPECIFIC CABLE C33, CONNECT PLUG TO DASH LIKE WE CAN SEE ON PHOTO BELOW AND RUN PROGRAM:

