

# MINI DASH FROM 2002 WITHOUT NAVI



USE CABLE **C45 + A6 ADAPTER**. REMOVE DASH FROM CAR, THEN CONNECT OR SOLDER CABLE LEADS ACCORDING TO COLOURS AS SHOWN ON PHOTOS BELOW:

