


MITSUBISHI CARISMA



USE CABLE C4, REMOVE FRONT AND BACK PLASTICS COVERS FROM DASH. THEN REMOVE NAIL AND ENGINE (ALL TOGETHER) FROM TACHOMETER, LIKE IN PHOTO, **IT IS A VERY GOOD IDEA TO USE IN MANY DASHBOARDS FROM ASIAN CARS:**



NOW ON THE MAIN BOARD LOOK FOR EPROM 93C46, AND AS WE CAN SEE ON THE PHOTOS CLIP IT AND MODIFY, ALWAYS CHECKING PIN 1:

