

# NISSAN MURANO FROM 2006



USE C7 CABLE, WE ONLY NEED TO REMOVE BACK PLASTIC COVER FROM DASH, LOCATE POINTS ON THE MAIN BOARD, LIKE IN PHOTO BELOW, AND SOLDER CABLE LEADS AS IT SHOWS TO US:

