

NISSAN NAVARA FROM 2006



USE CABLE C12, REMOVE BACK COVER FROM DASH, THEN CONNECT OR SOLDER CABLE LEADS ACCORDING TO COLOURS AS SHOWN OF BELOW PHOTO:

